



---

# VISIO

---

***RPM INDICATOR + SURFACE VERSION***

*Software rel. 2.3.x*

---

|                                                    |           |
|----------------------------------------------------|-----------|
| • Legend of symbols .....                          | 3         |
| <b>INTRODUCTION .....</b>                          | <b>4</b>  |
| Product description .....                          | 4         |
| <b>INTENDED USE .....</b>                          | <b>4</b>  |
| <b>CONTENT OF THE PACKAGE .....</b>                | <b>4</b>  |
| <b>PRECAUTIONS .....</b>                           | <b>4</b>  |
| <b>RISKS AND PROTECTIONS BEFORE ASSEMBLY .....</b> | <b>5</b>  |
| Positioning .....                                  | 5         |
| Power supply and sensor connection .....           | 5         |
| <b>ASSEMBLY DIAGRAMS .....</b>                     | <b>6</b>  |
| <b>CONTROLS IN THE MENU .....</b>                  | <b>7</b>  |
| First switching on .....                           | 7         |
| Controls in the menu .....                         | 8         |
| <b>MENU STRUCTURE .....</b>                        | <b>10</b> |
| <b>PRELIMINARY SETUP FOR USE .....</b>             | <b>11</b> |
| Speed alarms .....                                 | 11        |
| Sensors .....                                      | 12        |
| Speed sensor calibration .....                     | 13        |
| Language .....                                     | 16        |
| Units of measurement .....                         | 17        |
| Display contrast .....                             | 19        |
| Alarm tones .....                                  | 20        |
| Keytones .....                                     | 20        |
| Display settings .....                             | 21        |
| Boom length .....                                  | 22        |
| Operating mode .....                               | 23        |
| Setup management .....                             | 24        |
| Test menu .....                                    | 26        |
| <b>USE .....</b>                                   | <b>28</b> |
| Partial totalizer reset .....                      | 28        |
| <b>MAINTENANCE / DIAGNOSTICS / REPAIRS .....</b>   | <b>29</b> |
| Troubleshooting .....                              | 29        |
| <b>END OF LIFE DISPOSAL .....</b>                  | <b>29</b> |
| <b>TECHNICAL DATA .....</b>                        | <b>30</b> |
| Device technical data .....                        | 30        |
| Setup menu .....                                   | 31        |
| <b>GUARANTEE TERMS .....</b>                       | <b>32</b> |



= **Generic danger**



= **Warning**

*This manual is an integral part of the equipment to which it refers and must accompany the equipment in case of sale or change of ownership. Keep it for any future reference; ARAG reserves the right to modify product specifications and instructions at any moment and without notice.*

## INTRODUCTION

### Product description

VISIO is a very compact and accurate top-notch multifunction display, able to display any kind of information concerning agricultural treatments.

Operator can select the required function via software.

It can display several types of values, which change according to set operating mode and type of connected sensors.


### INTENDED USE

This device is designed to work on agricultural machinery for spraying and crop spraying applications.

**CE** The machine is designed and built in compliance with EN ISO 14982 standard (Electromagnetic compatibility - Forestry and farming machines), harmonized with 2014/30/UE Directive.

### CONTENT OF THE PACKAGE

The table below indicates the components that you will find in the VISIO package:



#### Legend:

- 1 VISIO
- 2 Fixing kit
- 3 Instruction manual (on CD-ROM)
- 4 Installation sheet

### PRECAUTIONS




- Do not aim water jets at the equipment.
- Do not use solvents or fuel to clean the case outer surface.
- Do not clean equipment with direct water jets.
- Comply with the specified power voltage (12 VDC).
- In case of voltaic arc welding, remove connectors from VISIO and disconnect the power cables.
- Only use ARAG genuine spare parts and accessories.

## RISKS AND PROTECTIONS BEFORE ASSEMBLY



All installation works must be done with battery disconnected, using suitable tools and any individual protection equipment deemed necessary.

### Positioning



1) Set mounting rail in cabin and fasten it with the relevant screws (1), in a position where VISIO can be easily seen and at hands' reach, but away from any moving organs.

2) Secure VISIO to rail and push down until locked in place.

3) Fasten wiring so that it does not interfere with any moving parts.

### Power supply and sensor connection




Sensors and power supply must be installed and connected by qualified personnel. VISIO must be exclusively connected to ARAG equipment.


**WHEN ARC WELDING IS REQUIRED, MAKE SURE THAT EQUIPMENT POWER IS SWITCHED OFF; DISCONNECT POWER CABLES IF NEEDED.**



ARAG is not liable for damage to the system, persons, animals or property caused by VISIO wrong or unsuitable assembly. Failure to observe the above instructions automatically voids the warranty.



| Wire color<br>(power cable) | Connection of                                                                                |
|-----------------------------|----------------------------------------------------------------------------------------------|
| red                         |  positive  |
| black                       |  negative |
| green                       | counting abort -<br>ground connection                                                        |
| yellow                      | counting abort -<br>connection +12VDC                                                        |



## Legend:

- 1) Power cable
- 2) Connection cable for double sensor
- 3) RPM sensor
- 4) Speed sensor

### First switching on

---



At first switching on, VISIO will run a guided procedure allowing user to set the device's basic settings.


Press  to scroll through items, **OK** to save and move on to next setting, or **ESC** to go back to previous setting.



**WARNING:** Before changing operating mode, make sure that all sensors / flowmeters are **DISCONNECTED** from the device.



In the following pages, according to the set operating mode, some menu items could slightly differ from the shown ones.



### SWITCHING ON


**A** Press for 1 second

**B** Press the key a few times to view the various values in extended mode, (on display central part)

Every time the device is switched on, it will shortly show a page with the name of device and software version.

### SWITCHING OFF

**A** Press for 2 seconds



### ACCESS TO SETUP MENU

From the main page, press keys at the same time for 2 seconds to open the Setup Menu.



## SELECTION AND ACCESS TO MENU ITEMS

**A** Press a few times to scroll through items (selected item is indicated by a black line)

**B** Press to open the selected menu item



The three dots under an item indicate presence of another setup menu.



## EDITING A VALUE

**A** Press to move through digits


**B** Press a few times to edit the highlighted digit

**C** Press to confirm. The display goes back to previous page

**D** Press to exit page without confirming modification



Edited value must fall within the range shown.



## Alarms

Min speed  
Max speed  
Sens. 1 min Rpm  
Sens. 1 max Rpm

## Sensors

Speed sensor  
Rpm 1  
Man. calibration  
Auto calibration  
Man. calibration

## Options

Language  
Units of measurem.  
Speed  
Km/h  
MPH  
Length  
m  
ft  
Surface  
ha  
acres  
Ksqft  
Distance  
Km  
Miles  
Display contrast  
Alarm tones  
Keytones  
Display settings  
Data 1 } Surface TOT 1  
Data 2 } Surface TOT 2  
Data 3 } Distance TOT  
Speed  
Rpm sensor 1  
Sens. 1 min Rpm  
Sens. 1 max Rpm  
Rpm sens. 1 time  
Boom width  
Operating mode  
Rpm / Sur. coun.  
.....  
.....

## Setup management


Salva config.  
Carica config.

## Test

Firmware version  
Battery voltage  
Display  
Keys  
Sensors

## Speed alarms

Set minimum and maximum speed thresholds for alarm message.




1) Open Alarm menu (Setup menu > Alarms).



**Minimum and maximum speed alarms are set in the same way.**

**The display will show the current setting below the selected item.**

Press **OK** to edit the selected menu item.



2) To activate the alarm, press  and



key at the same time until message

OFF goes off and speed alarm value is displayed instead.

Carry out the same procedure to disable alarm again.




3) Set alarm value:

A) Press to move through digits.

B) Press a few times to edit the highlighted digit.

C) Press to save changes, or

D) Press to quit the page without confirming changes.



1) Open Sensors menu (Setup menu > Sensors).

The menu items displayed below change according to the set operation mode: when more items are available, select the desired one and press **OK** to edit it.

## Speed sensor calibration

---

VISIO calculates the information concerning the speed thanks to pulses received by the sensor installed on the wheel.

To perform calibration, proceed as follows:

- Measure a straight path at least 100 m (300 feet) long.

The longer the distance traveled, the more accurate the wheel constant calculation.

- Take measurements with tyres at the operating pressure.


This test must be performed on medium-hard terrain; for application to very soft or very hard terrain, rolling diameter may vary, leading to inaccurate output calculation; when this is the case, repeat the procedure.

During the test, cover the distance with the tank filled up to half capacity with water.

Calculate and save the wheel constant according to the procedure below:



1) Open automatic calibration menu (Setup menu > Sensors > Speed sensor > Auto Calibration).



As soon as menu is open, the equipment is ready to start measuring with no further controls being required.



Cover the requested distance: the number of pulses will increase during the path and the bottom area will indicate instant speed reading.

Stop the tractor at the end of the distance.

 If a malfunction occurs, the message **Check sensor!** will be shown in the top part of the display.



Press **OK** to stop the counting. The display will go back to the previous menu and will show the acquired value.

In case of measurement errors, or if it is necessary to stop the calibration, press **ESC** for 2 seconds to quit the calibration procedure without saving.

In this case, the value will be the one previously measured, or the default value.

Manual calibration allows to enter the wheel constant value calculated with the suitable formula:


$$K_{\text{wheel}} = \frac{\text{distance traveled (cm)}}{\text{no. of detection points} \times \text{wheel rpm}}$$

**<distance traveled>** distance expressed in cm covered by the wheel along measurement travel;


**<no. of measurement points>** number of measurement points (e.g., magnets, bolts, etc.), mounted on wheel;

**<no. of wheel revolutions>** number of wheel revolutions required to travel measurement distance.

The wheel constant can be calculated with a good approximation by detecting the distance traveled by the wheel with the speed sensor.



1) Open manual calibration menu (Setup menu > Sensors > Speed sensor > Man. Calibration).



Cover the requested distance. Stop the tractor at the end of the distance and calculate wheel constant ( $K_{\text{wheel}}$ ).

2) Set wheel constant value:

A) Press to move through digits.


B) Press a few times to edit the highlighted digit.

C) Press to save changes, or

D) Press to quit the page without confirming changes.

## Language

Set the desired language.



Open language setting menu (Setup menu > Options > Language).

**The display will show the current setting below the selected item.**

Press **OK** to edit language.




1) Select a language through .

2) Press **OK** to save, or **ESC** to quit without saving.

## Units of measurement

Set unit of measurement for the values detected by the device.

### Speed unit of measurement



Open speed unit of measurement setting menu (Setup menu > Options > Units of measurem. > Speed).

**The display will show the current setting below the selected item.**


Press **OK** to select speed unit of measurement.



1) Select a unit through .

2) Press **OK** to save, or **ESC** to quit without saving.


### Length units of measurement



Open length unit of measurement setting menu (Setup menu > Options > Units of measurem. > Length).


**The display will show the current setting below the selected item.**

Press **OK** to select length unit of measurement.



1) Select a unit through .

2) Press **OK** to save, or **ESC** to quit without saving.



Open surface unit of measurement setting menu (Setup menu > Options > Units of measurement. > Surface).

**The display will show the current setting below the selected item.**


Press **OK** to select surface unit of measurement.



1) Select a unit through .

2) Press **OK** to save, or **ESC** to quit without saving.

## Distance units of measurement



Open distance unit of measurement setting menu (Setup menu > Options > Units of measurement. > Distance).

**The display will show the current setting below the selected item.**

Press **OK** to select distance unit of measurement.




1) Select a unit through .

2) Press **OK** to save, or **ESC** to quit without saving.

## Display contrast

### Set display contrast.



Open display contrast menu (Setup menu > Options > Display contrast).

**The display will show the current setting below the selected item.**

Press **OK** to edit the selected menu item.




1) Set a value through . Every time you press it, value will increase by 5% up to 100%. Use key  to decrease value by 5%.

2) Press **OK** to save, or **ESC** to quit without saving.

## Alarm tones

Enable/disable the alarm tones.



Open alarm tones menu (Setup menu > Options > Alarm tones).

**The display will show the current setting below the selected item.**

Press **OK** to edit the selected menu item.




1) Set status through .

2) Press **OK** to save, or **ESC** to quit without saving.

## Keytones

Enable/disable keytones.



1) Open keytones menu (Setup menu > Options > Keytones).


**The display will show the current setting below the selected item.**

Press **OK** to edit the selected menu item.




1) Set status through .

2) Press **OK** to save, or **ESC** to quit without saving.




The main page shows the display divided into three horizontal parts, which can be separately reset (according to the value). Every sector can be assigned the desired value:

- **TOT 1-2 surf.** = Total surface covered;
- **TOT distance** = Total distance covered;
- **Speed** = Detected instant speed;
- **Rpm sensor 1** = Rpm live reading;
- **Min. Rpm sens. 1** = minimum detected Rpm;
- **Max. Rpm sens. 1** = maximum detected Rpm;
- **RPM sens. time 1** = value, measured in seconds, during which VISIO has detected a movement of the rotating part.




Open Display settings menu (Setup menu > Options > Display settings).

Press **OK** to edit the selected menu item.



1) Select value through .

2) Press **OK** to edit, or **ESC** to quit without saving.



1) Set sector to the required value


through .

2) Press **OK** to save, or **ESC** to quit without saving.

Carry out the same procedure for the other 2 values.

## Boom length

Set boom length.



1) Open the boom length menu (Setup menu > Options > Boom length).

**The display will show the current setting below the selected item.**

Press **OK** to edit the selected menu item.



2) Set boom length:

A) Press to move through digits.


B) Press a few times to edit the highlighted digit.

C) Press to save changes, or

D) Press to quit the page without confirming changes.

## Operating mode


Set required operating mode.



Open operating mode menu (Setup menu > Options > Operating mode).

**The display will show the current setting below the selected item.**


Press **OK** to change the operating mode.



1) Select the required operating mode

through .

2) Press **OK** to save, or **ESC** to quit without saving.



**WARNING:** Once **OK** is pressed, the page on the side will be displayed.

**Before changing operating mode, make sure that all sensors are DISCONNECTED from the device.**

Press **OK** to confirm changes.

**Connect the sensors REQUIRED FOR THE SET OPERATING MODE.**

## Setup management

VISIO settings can be loaded from or saved on a USB pen drive in order to reconfigure it if required, fix problems or set another VISIO with no need to repeat all manual operations.



Once installation is completed, and VISIO operation has been checked, we recommend to save all settings onto a USB pen drive.

To be able to use the following functions it is necessary to insert a USB pen drive in the relevant port at the bottom of VISIO.



1) Open Setup management menu (Setup menu > Setup management).

Press **OK** to edit the selected menu item.



### Load setup

Allows to select a configuration file saved in the USB pen drive and to set VISIO again.

**WARNING:** By loading the **SETUP.BIN** file contained in the USB pen drive onto the VISIO, all current settings will be lost.

1) Select the desired control through

2) Press **OK** to confirm loading, or **ESC** to quit without saving.

The **SETUP.BIN** file can be loaded only if it is saved in the USB pen drive root directory.

If setup download involves changing operating mode and using different sensors than the ones in use, make sure that all sensors are **DISCONNECTED** from the device.

Press **OK** to confirm loading.

Reconnect sensors.



### Save setup

Allows saving VISIO configuration file on the USB pen drive: it will be possible to load it again any time the same settings need to be retrieved.

1) Select the desired control through



key.

2) Press **OK** to confirm saving, or **ESC** to quit without saving.

 If a **SETUP.BIN** file is already present in the USB pen drive root directory, the file will be overwritten.

## Test menu

This menu allows user to view some data and carry out an operation test of VISIO:

**- Firmware version:**


the display shows the firmware version installed.

**- Battery voltage:**

the display shows the power voltage of the device.


### Display test

Display test checks the device display correct operation.



1) Open display test menu (Setup menu > Test > Display).

Press **OK** to perform the test.




All pixels on display are turned on.

Press **ESC** to go back to previous page.

### Keys test

Keys test checks the device keys correct operation.



Open keys test menu (Setup menu > Test > Keys).


Press **OK** to perform the test.



1) Press any key and the corresponding display area will turn on.


Press **ESC** to quit: as soon as you acknowledge the switch-on on of the corresponding area on the display, device will go back to previous page.

Sensors test checks correct operation of the sensors connected to the device.



Open sensors test menu (Setup menu > Test > Sensors).

Press **OK** to perform the test.



The display will show the current sensor reading below the selected item.

1) Several sensors could be displayed, depending on the set operating mode. In this case, select required sensor

through .

2) Press **ESC** to quit.



Depending on set data, activate the rotating part, or start the vehicle. The display will start showing the detected value.

### Partial totalizer reset






To reset a peak value or a totalizer, it is necessary to view it in extended mode. Press key several times until value to be reset is at the central area of the display.



Press  for two seconds.  
The value resets.

Symbol  indicates that the value exceeds the maximum value that can be displayed.

Totalizers display maximum 4 digits.



...

## MAINTENANCE / DIAGNOSTICS / REPAIRS

- Clean only with a soft wet cloth.
- Do not use aggressive detergents or products.
- Do not clean equipment with direct water jets.

### Troubleshooting

| FAULT                                | CAUSE                        | REMEDY                                |
|--------------------------------------|------------------------------|---------------------------------------|
| VISIO is off or does not switch on   | No power supply              | Check power cable connections         |
|                                      | Device is OFF                | Press the ON key                      |
| VISIO shows wrong data               | Wrong setup                  | Check displayed data setup            |
|                                      | Sensor fault                 | Contact the nearest Assistance Center |
|                                      | VISIO fault                  |                                       |
| Filling pump (if any) does not start | Pump Stop Module not powered | Check power supply connection         |

## END OF LIFE DISPOSAL

Dispose of the system in compliance with the established legislation in the country of use.

## TECHNICAL DATA

### Device technical data

| Description                                     | VISIO                                       |
|-------------------------------------------------|---------------------------------------------|
| Display                                         | Graphic LCD, 128 x 64 pixels, back-lighting |
| Power supply voltage                            | 9 ÷ 16 Vdc                                  |
| Protection against short-circuit                | •                                           |
| Protection against polarity inversion           | •                                           |
| Max. frequency                                  | 1.2 KHz                                     |
| Analog inputs                                   | 4 ÷ 20 mA                                   |
| Digital output - Max current                    | 100 mA                                      |
| Maximum power input (with no sensors connected) | 160 mA                                      |
| Operating temperature                           | -20 °C ÷ 70 °C<br>-4 °F ÷ +158 °F           |
| Storage temperature                             | -30 °C ÷ 80 °C<br>-22 °F ÷ +176 °F          |
| Size                                            | 126 x 79 x 66 mm                            |
| Weight                                          | 245 g                                       |

## Setup menu

|                | Data                                 | Min. | Max.  | Default | UoM   | Notes                                                                                                                              |
|----------------|--------------------------------------|------|-------|---------|-------|------------------------------------------------------------------------------------------------------------------------------------|
| <b>Sensor</b>  | <b>Calibration</b>                   | 1.0  | 200.0 | 60.0    | pls/l | --                                                                                                                                 |
| <b>Alarms</b>  | <b>Min. speed</b>                    | 1    | 100   | OFF     | km/h  | Alarm can be disabled by setting value to "OFF"                                                                                    |
|                | <b>Max. speed</b>                    | 1    | 100   | OFF     | km/h  | Alarm can be disabled by setting value to "OFF"                                                                                    |
|                | <b>Min. Rpm</b>                      | 1    | 9999  | OFF     | RPM   | Alarm can be disabled by setting value to "OFF"                                                                                    |
|                | <b>Max. Rpm</b>                      | 1    | 9999  | OFF     | RPM   | Alarm can be disabled by setting value to "OFF"                                                                                    |
| <b>Display</b> | <b>Contrast</b>                      | 0    | 100   | 50      | %     | --                                                                                                                                 |
| <b>Options</b> | <b>Language</b>                      | -    | -     | English | -     | <b>Available languages:</b> Italiano, English, Español, Português, Français, Deutsch, Cesky, Polski, Русский, Magyar, <b>日本語</b> . |
|                | <b>Speed units of measurement</b>    | -    | -     | km/h    | -     | <b>Available units of measurement:</b> km/h, MPH                                                                                   |
|                | <b>Length units of measurement</b>   | -    | -     | m       | -     | <b>Available units of measurement:</b> m, ft                                                                                       |
|                | <b>Surface units of measurement</b>  | -    | -     | ha      | -     | <b>Available units of measurement:</b> ha, acri, ksqft                                                                             |
|                | <b>Distance units of measurement</b> |      |       | km      | -     | <b>Available units of measurement:</b> km, miles                                                                                   |

## **GUARANTEE TERMS**

---

1. ARAG s.r.l. guarantees this apparatus for a period of 360 days (1 year) from the date of sale to the client user (date of the goods delivery note).  
The components of the apparatus, that in the unappealable opinion of ARAG are faulty due to an original defect in the material or production process, will be repaired or replaced free of charge at the nearest Assistance Center operating at the moment the request for intervention is made. The following costs are excluded:
  - disassembly and reassembly of the apparatus from the original system;
  - transport of the apparatus to the Assistance Center.
2. The following are not covered by the guarantee:
  - damage caused by transport (scratches, dents and similar);
  - damage due to incorrect installation or to faults originating from insufficient or inadequate characteristics of the electrical system, or to alterations resulting from environmental, climatic or other conditions;
  - damage due to the use of unsuitable chemical products, for spraying, watering, weedkilling or any other crop treatment, that may damage the apparatus;
  - malfunctioning caused by negligence, mishandling, lack of know how, repairs or modifications carried out by unauthorized personnel;
  - incorrect installation and regulation;
  - damage or malfunction caused by the lack of ordinary maintenance, such as cleaning of filters, nozzles, etc.;
  - anything that can be considered to be normal wear and tear.
3. Repairing the apparatus will be carried out within time limits compatible with the organizational needs of the Assistance Center.  
No guarantee conditions will be recognized for those units or components that have not been previously washed and cleaned to remove residue of the products used;
4. Repairs carried out under guarantee are guaranteed for one year (360 days) from the replacement or repair date.
5. ARAG will not recognize any further expressed or intended guarantees, apart from those listed here.  
No representative or retailer is authorized to take on any other responsibility relative to ARAG products.  
The period of the guarantees recognized by law, including the commercial guarantees and allowances for special purposes are limited, in length of time, to the validities given here.  
In no case will ARAG recognize loss of profits, either direct, indirect, special or subsequent to any damage.
6. The parts replaced under guarantee remain the property of ARAG.
7. All safety information present in the sales documents regarding limits in use, performance and product characteristics must be transferred to the end user as a responsibility of the purchaser.
8. Any controversy must be presented to the Reggio Emilia Law Court.



## **CONFORMITY DECLARATION**

---

The declaration of conformity is available at [www.aragnet.com](http://www.aragnet.com), in the relevant section.

---

*Only use genuine ARAG accessories or spare parts to make sure manufacturer guaranteed safety conditions are maintained in time. Always refer to the internet address [www.aragnet.com](http://www.aragnet.com)*

D20287\_GB-m04 03/2017



42048 RUBIERA (Reggio Emilia) - ITALY  
Via Palladio, 5/A

Tel. +39 0522 622011

Fax +39 0522 628944

[www.aragnet.com](http://www.aragnet.com)

[info@aragnet.com](mailto:info@aragnet.com)