





The sequence valve VDS/B has to be set at least 10 bar higher than the VRPRL/V (= ground pressure)
E.G.: C2 = 25bar than A or M1 has to be 35bar at least