



Scale for **Wile-55** moisture meter for **Field beans**.

Use scale -0-

<u>Meter reading</u>	<u>% Moisture content</u>
1940	8.8
1920	10.0
1900	11.3
1890	11.9
1880	12.5
1870	13.1
1860	13.6
1850	14.1
1840	14.6
1830	15.1
1820	15.5
1810	15.9
1800	16.2
1780	16.8
1760	17.3
1740	17.8
1720	18.3
1700	18.7
1680	19.1
1660	19.4
1640	19.8
1620	20.2
1600	20.5
1550	21.4
1500	22.3
1450	23.1
1400	23.9
1350	24.7
1300	25.5
1250	26.3
1200	27.1
1150	27.9
1100	28.7
1050	29.5
1000	30.3

For further details including calibration and repairs please contact your dealer.