



Draw bar




Code	Description	Kramp item code
101	Release Rod	PTS2500KR101
102	Chain	PTS2500KR102
103	Adjusting Bold	PTS2500KR103
104	Adjusting Nut	
105	Axle with Hole	PTS2500KR105
106	Elastic Pin	
107	Bushing	
108	Roller Pin	
109	Pressure Roller	
109A	Bushing	
110	Draw Bar	
111	Stop Rubber	
112	Elastic Pin	
113	Blade Spring	
114	Spring	
115	Elastic Pin	
116	Elastic Pin	
117	Control Handle	PTS2500KR117
118	Roller	
119	Elastic Pin	
	Draw Bar complete	PTS2500KR199

Fork frame



Code	Description	Kramp item code
203	Rock Arm	
204	Bushing	
205	Shaft	
206	Bushing	
207	Bushing	
208	Retaining Ring	
B209	Joint	
B211	Nut	
B212	Pushing Rod	
213	Retaining Ring	
214	Shaft	
216	Shaft	
217	Intermediate Roller	
218	Extending Roller	
221	Shaft	
222	Frame of Roller	
223D	Shaft for Roller	
224D	Linking Plate	
227	Loading Roller (Poliure	WH200P8270
228	Tandem Mounting	
232	Enter Roller	PTS2500KR232

Pump



Code	Description	Kramp item code
301	Spring Cap	
302	Spring	
303	Pump Piston	
304	Dust Ring	
305	Seal	
306	Dust Cover	PTS2500KR306
307	Locking Ring	
308	Washer	
309	Bearing	
310	Loading Wheel (Poliure	PTS2500KR310PU
311	Elastic Pin	
312	Elastic Pin	
313	Thrust Plate	
314	Retaining Ring	
315	Bearing	
316	Shaft of Loading Wheel	
317	Nut	
318	Screw	
319	Lever Plate	
320	Elastic Pin	
321	Valve Cartridge	
322Y	Pump Body	
	Seal Kit	PTS2500KR399